

# COMMUNICATION PROTOCOL

VERSION : 2.7

CHECKED BY :

PREPARED BY :

DATE : SEP. 30, 1995

FILE :MEGAPRO7.DOC

DATE :V2.7 : JULY 30 ,1996

	DATE	DESCRIPTION	MODIFY BY
2.6	95-9-30	UPDATE "D" COMMAND (SS.SS -> SSS.SS)	Kevin Chiou
2.7	96-8-01	Disable "D" COMMAND	Kevin Chiou

MEGATEC COMMUNICATION PROTOCOL

A. General: This document specifies the RS232C communication protocol of the Advance-Intelligent UPS. The protocol provided the following features :

1. Monitor charger status.
2. Monitor battery status and condition.
3. Monitor the utility status.
4. Provide the power switch function for computer to turn on and off the utility on schedule for power saving.

Computer will control information exchange by a query followed by <cr>. UPS will respond with information followed by a <cr> or action.

#### B. Hardware:

BAUD RATE..... : 2400 bps  
 DATA LENGTH..... : 8 bits  
 STOP BIT..... : 1 bit  
 PARITY..... : NONE

#### CABLING :

COMPUTER	UPS	
RX <-----	TX (pin 9)	TX ----
-----> RX (pin 6)		
GND <-----	GND (pin 7)	
(9 pins female D-type connector)		

#### C. COMMUNICATION PROTOCOL:

##### 1. Status Inquiry:

Computer : Q1<cr>

UPS : UPS status data stream, such as

(MMM.M NNN.N PPP.P QQQ RR.R S.SS TT.T b7b6b5b4b3b2b1b0<cr>

UPS status data stream :

There should be a space character between every field for data separation. The meaning of each field is list as followed:

a. Start byte : (

b.I/P voltage : MMM.M

M is an integer number ranging from 0 to 9.

The unit is Volt.

c.I/P fault voltage : NNN.N

N is an integer number ranging from 0 to 9.

The unit is Volt.

\*\* For OFF LINE UPS\*\*

Its purpose is to identify a short duration voltage glitch which cause OFF line UPS to go to Inverter mode. If this occurs input voltage will appear normal at query prior to glitch and will still appear normal at next query.

The I/P fault voltage will hold glitch voltage till next query. After query, the I/P fault voltage will be same as I/P voltage until next glitch occurs.

\*\* For ON LINE UPS\*\*

Its purpose is to identify a short duration utility fail which cause ON line UPS to go to battery mode. If this occurs input voltage will appear normal at query prior to fail and will still appear normal at next query.

The I/P fault voltage will hold utility fail voltage till next query. After query, the I/P voltage will be same as I/P voltage until next utility fail occurs.

d.O/P voltage : PPP.P

P is an integer number ranging from 0 to 9.

The unit is Volt.

e.O/P current : QQQ

QQQ is a percent of maximum current, not an absolute value.

f.I/P frequency : RR.R

R is an integer number ranging from 0 to 9.

The unit is HZ.

g.Battery voltage : SS.S or S.SS

S is an integer number ranging from 0 to 9.

For on-line units battery voltage/cell is provided in the form S.SS .

For standby units actual battery voltage is provided in the form SS.S .

UPS type in UPS status will determine which reading was obtained.

h.Temperature : TT.T

T is an integer number ranging form 0 to 9.  
The unit is degree of centigrade.

i. UPS Status : <U>

<U> is one byte of binary information such as <b7b6b5b4b3b2b1b0>.

Where bn is a ASCII character '0' or '1'.

. j. Stop Byte : <cr>

UPS status :

Bit	Description
7	1 : Utility Fail (Immediate)
6	1 : Battery Low
5	1 : Bypass/Boost or Buck Active
4	1 : UPS Failed
3	1 : UPS Type is Standby (0 is On_line)
2	1 : Test in Progress
1	1 : Shutdown Active
0	1 : Beeper On

Example: Computer : Q1<cr>

UPS :

(208.4 140.0 208.4 034 59.9 2.05 35.0 00110000<cr>

Means : I/P voltage is 208.4V.

I/P fault voltage is 140.0V.

O/P voltage is 208.4V.

O/P current is 34 %.

I/P frequency is 59.9 HZ.

Battery voltage is 2.05V.

Temperature is 35.0 degrees of centigrade.

type is on-line , UPS failed. Bypass

UPS  
active , and shutdown not active.

---

2. Test for 10 seconds:

Computer : T<cr>

UPS : Test for 10 seconds and return to utility.

If battery low occur during testing, UPS will return to utility immediately.

3. Test until battery low :

Computer : TL<cr>

UPS : Test until battery low and return to utility.

4. Test for specified time period :

Computer : T<n><cr>

UPS : Test for <n> minutes.

- a. During testing, UPS returns to utility immediately, if battery low occur.
- b. <n> is a number ranging from 01 to 99.

5. Turn On/Off beep -- Toggle the UPS beeper :

Computer : Q<cr>

When the AC power failed, UPS will generate a warning beep to inform the manager. Manager could toggle the warning beep by sending this command .

6. Shutdown Command :

Computer : S<n><cr>

UPS : Shut UPS output off in <n> minutes.

- a. The UPS output will be off in <n> minutes, even if the utility power is present.

- b. If the battery low occurs before <n> minutes, the output is turned off immediately.
- c. After UPS shutdown, the controller of UPS monitors the utility power. If the utility is recovered, the UPS will wait for 10 seconds and connect the utility to output.
- d. <n> is a number ranging form .2, .3, ..., 01, 02, ..., up to 10.

For example : S.3<cr> --- shut output off in (.3) minutes

#### 7. Shutdown and Restore Command :

Computer : S<n>R<m><cr>

UPS : Shut UPS output off in <n> minutes, and waiting for <m> minutes then turn on UPS output again.

- a. The shutdown sequence is the same as the previous command. When the <m> minutes expired, the utility do not restore, the UPS will wait until utility restore.
- b. If UPS is in shutdown waiting state, the "C" command can let the shutdown procedure cancelled.
- c. If UPS is in restore waiting state, the "C" command can let the UPS output turned on, but UPS must be hold off at least 10 seconds. (if utility is present)
- d. <n> is a number ranging form .2, .3, ..., 01, 02, ..., up to 10.
- e. <m> is a number ranging form 0001 to 9999.

#### 8. Cancel Shutdown Command :

Computer : C<cr>

UPS : Cancel the SN<n><cr> and SN<n>R<m><cr> command.

- a. If UPS is in shut down waiting state, the shut down command is cancelled.
- b. If UPS is in restore waiting state, the UPS output is turned on, but UPS must be hold off at least 10 seconds.

---

(if utility is present)

9. Cancel Test Command :

Computer : CT<cr>

UPS : Cancel all test activity and connect the utility to output immediately.

10. UPS Information Command:

Computer : I<cr>

UPS : #Company\_Name UPS\_Model Version<cr>

This function will make the UPS respond with the basic information about the company who manufacture the UPS, the model name of the UPS and the version number of the UPS firmware.

The length of every field is listed as follows:

Company\_Name : 15 characters, leave space if less than 15 characters

UPS\_Model : 10 characters, leave space if less than 10 characters

Version : 10 characters, leave space if less than 10 characters

There should be a space character between every field for separation.

11. UPS Rating Information:

Computer : F<cr>

UPS : #MMM.M QQQ SS.SS RR.R<cr>

This function makes the UPS answer the rating value of UPS. There should be a space character between every field for separation. The UPS's response contains the following information field:

a. Rating Voltage : MMM.M

b. Rating Current : QQQ

c. Battery Voltage : SS.SS or SSS.S

d. Frequency : RR.R

## 12. Status Inquiry:

Computer :W1<cr>

UPS :UPS status data stream, such as  
( #MMMM b3b2b1b0<cr>

There should be a space character between every field for data separation. The meaning of each field is list as followed:

MMMM - batt remaining time in minutes (0000 - 9999 min)

b3 - batt connection status (0 - disconnect, 1 connect)

b2 - Overtemp Alarm (0 - no alarm, 1 - alarm)

b1- Overload alarm (0 - no alarm, 1 - alarm)

b0 - Short circuit alarm (0 - no alarm, 1 - alarm)

## 13. Used for one power down

Computer : L<n><cr>

UPS :Cut off the load power supply in <n> minutes

a. This function: When the UPS working mode is in battery mode, the rectifier module has no direct output, and the battery is discharged. If the customer clicks once to power off, the power supply of the load connected to the UPS output side will be cut off.

b. <n> is a number ranging form .001 up to 999.

## 14. Used for two power down

Computer :J<n><cr>

UPS :Turn off the inverter in <n> minutes

a. This function: When the UPS is in battery operation mode, after the customer inputs this instruction, the UPS shuts down the inverter and the machine is in shutdown state

b. <n> is a number ranging form .001 up to 999.

## 15. Used to cancel one power off

Computer :Z<cr>

UPS : Cancel the L<n><cr> command.

a. If the UPS is in a power down waiting state, the power down command is cancelled.



---

b. If the UPS is in the recovery waiting state, the ups output will turn on

16. Used to cancel two power off

Computer :Y<cr>

UPS : Cancel the J<n><cr> command.

a. If UPS is in shut down waiting state, the shut down command is cancelled.

b. If UPS is in restore waiting state, the UPS output is turned on.

## D. COMMAND SUMMARY:

ITEM	COMMAND	DESCRIPTION
1a	D	Status Inquiry *disable
1	Q1	Status Inquiry
2	T	10 Seconds Test
3	TL	Test until Battery Low
4	T<n>	Test for Specified Time Period
5	Q	Turn On/Off beep
6	S<n>	Shut Down Command
7	S<n>R<m>	Shut Down and Restore Command
8	C	Cancel Shut Down Command
9	CT	Cancel Test Command
10	I	UPS Information Command
11	F	UPS Rating Information
12	W1	Status Inquiry
13	L<n>	Used for one power down
14	J<n>	Used for two power down
15	Z	Used to cancel one power off
16	Y	Used to cancel two power off

## E. Invalid Command/Information Handling

If the UPS receives any command that it could not handle, the UPS should echo the received command back to the computer. The host should check if the command send to UPS been echo or not.

If there is any information field in the UPS's response which is unavailable or not supported, the UPS should fill the field with '@'.